

CHAMELEON

Installation Guide




Rear View



CHAMELEON

Single Hardware Headend

THE CHAMELEON PRODUCT LINE COVERS ALMOST EVERY NEED FOR CABLE-TV AND SMATV DISTRIBUTION WITH ONLY ONE HARDWARE..

The different inputs, processing and outputs are defined by software options, and all software options can be updated at any time.

The CHAMELEON includes a dual DVB-S/S2/T/T2/C receiver, furthermore it includes decoding of MPEG-2 and MPEG-4 video formats as well

as it supports MPEG, AAC HE and Dolby audio decoding. The Dolby audio decoding requires the latest HW version.

The SW options define the different "product realisations" you can implement with the unique HW. For your specific application, you simply buy the SW options you need. When you need further functionality, just purchase additional SW options, and update the installed HW.



CHAMELEON Product examples

- Receiver DVB-S/S2/T(T2)/C
- Transmodulators
- DVB-C, DVB-T modulators
- DTMB modulator
- Analog VSB RF-modulators
- FM modulator
- Edge QAM/COFDM
- Dual MPEG2/4 SD decoder
- Single MPEG2/4 HD decoder
- CI multi-decryptions
- Remultiplexer multiple TS
- DVB_CSA Scrambler
- IP streamer
- ASI streamer
- SDI generator

Support

For support information and help, please contact our support organisations. Taylor in Oldham

m.rea@btinternet.com

Telephone:
0161484 3100



1 Getting started

Your Chameleon Unit comes pre configured as your order so all you have to do is set the RF frequency and video settings if required



The screenshot shows the Chameleon control web interface. At the top right is the 'CHAMELEON control' logo. Below it is a navigation bar with five tabs: 'STATUS' (highlighted), 'INPUTS', 'OUTPUTS', 'SERVICE MANAGEMENT', and 'SETTINGS'. The main content area is divided into four sections:

- MODULE IDENTIFICATION**: A table with fields for Serial (0430011081500005), Hardware revision (1102), Name (Chameleon 1), Location (GN40), and Description (S/S2/T/C). An 'EDIT' button is at the bottom right.
- CONFIGURATION**: A table with fields for Operation mode (DVB-T mode), Software version (2.0), and Software options (GNALL, GNHWUW).
- STATUS**: A table with fields for Uptime (02m 09s) and Temperature (47.5 °C).
- SERVICE LICENSE AGREEMENT (SLA)**: A table with fields for Demo (Terminated), Registered (Yes), and Expires (2014-10-09).

Available software options

INPUT	PROCESSING	OUTPUT	MISCELLANEOUS
DVB-C Receivers GNC, GNDC	Common Interface Decryption GNCI, GNDCI	DVB-C Modulators GNCMOD, GNDCMOD, GNQCMOD	MPEG Encoder GNHWENC
DVB-S/S2 Receivers GNS2, GNDS2	Simulcrypt Scrambling GNSCR	J.83 Annex B/C Modulators GNJ83B, GNDJ83B, GNJDJ83C, GNQJ83C	System Management GNSYSMG
DVB-T/T2 Receivers GNT, GNDT, GNT2, GNDT2	Remultiplexing GNMUX, GNSYMUX	DVB-T Modulators GNTMOD, GNDTMOD	Service License Agreement GNM1, GNM3
ASI input & output GNASI, GNDASI	Redundancy GNRED	Analogue Modulators GNVMOD, GNDVMOD	All Software Options GNALL
IP Streaming input & output GNSTR, GNSTREC	Dolby AC3 GNDOL	FM Radio GNDFM, GNOCFM	
		DTMB Modulator GNDMOD	
		SDI output GNSSDI, GNDSDI	
		ASI input & output GNASI, GNDASI	
		IP Streaming input & output GNSTR, GNSTREC	

3 Chameleon in GN50

NOTE!

For Chameleon running FW2.0 and installed in a GN50, please make sure that the GN50/GT11 FW is upgraded to SW version 2.0.

Most of the functionality of FW2.0 will be possible to access while running FW1.1.1 in GN50, but new functionality added in FW2.0 for Chameleon, such as IP VBR input to digital output is only possible to manage via the System UI if the GN50 is upgraded to SW2.0. Functionalities not supported via the System UI can still be managed when connected directly to the management IP address of the Chameleon.

For more information about this SW version for GN50, and for access to the SW2.0 file, please refer to documents .




7 Connecting to the CHAMELEON user interface

Default IP address: 192.168.0.20

The default IP address for a CHAMELEON module is 192.168.0.20. Change the IP address to a unique IP address in your network, in the web UI under **Settings / Networking**, or by using the **IP-Supporter**.

Connecting with web browser

Use a standard web browser on your computer to connect by typing the IP address of the CHAMELEON in the address field.



Supported web browsers

The CHAMELEON web interface is verified for Firefox version 14 and Internet Explorer 9. Other browsers might work, but the functionality cannot be guaranteed.

General information about the web interface structure

The web UI is designed to get a logical structure for the user/installer, and an overview of the module via the top tabs.

Operation mode must be selected before starting to use the CHAMELEON. The selected Operation mode will have implications on the general functionality of the module, e.g. the possible output standard and the IP streaming capability. The main interface while managing services is the **Service Management**. Here, you will have an overview of the configured inputs and outputs, and you will also manage the service selection, remultiplexing and decryption. Before you start managing the services, you should add and configure the inputs and the outputs in their respective tabs.



The **Settings** tab contains module settings such as Networking, Headend System Management, Operation Mode, Common Interface, SW and Entitlement Upgrade, Maintenance, and Log. The CAM menu, if available, is also displayed in the Common Interface menu under the Settings tab.

8 Select operation mode

Your equipment comes pre configured additional functions listed below can be added ,contact m.rea@btinternet.com

Operation mode

The operation mode changes the available outputs. You can read more about the modes down below.

Analog mode

☐ For analog RF (PAL, SECAM) modulation, and for SDI output. Up to 2 outputs are possible; the specific number is depending on the SW options enabled in the module, c.f. SW options GN xVMOD and GN xSDI. Simultaneously: ASI in/out max 2, max 4 IPTS out and max 2 IPTS in.

DVB-T mode

☒ For digital terrestrial modulation (COFDM). Up to 2 outputs are possible; the specific number is depending on the SW options enabled in the module, c.f. SW options GN xTMOD. Simultaneously: ASI in/out max 2, max 4 IPTS out and max 20 IPTS in.

DVB-C mode

☐ For digital cable TV modulation (QAM). Up to 4 outputs are possible; the specific number is depending on the SW options enabled in the module, c.f. SW options GN xCMOD. Simultaneously: ASI in/out max 2, max 6 IPTS out and max 20 IPTS in.

J.83 Annex B mode

☐ For J.83 Annex B modulation with DVB-PSI/SI meta data. Up to 2 outputs are possible; the specific number is depending on the SW options enabled in the module, c.f. SW options GN xJ83B. Simultaneously: ASI in/out max 2, max 4 IPTS out and max 20 IPTS in.

J.83 Annex C mode

☐ For J.83 Annex C modulation with DVB-PSI/SI meta data. Up to 4 outputs are possible; the specific number is depending on the SW options enabled in the module, c.f. SW options GN xJ83C. Simultaneously: ASI in/out max 2, max 4 IPTS out and max 20 IPTS in.

Streaming mode

☐ For IP-TV output (TS over IP). The streaming mode requires the GN STRx SW options. Max 20 IPTS out.

FM mode

☐ For FM (radio) output. The FM mode requires the GN DFM (dual FM) or the GN OCTFM (8 FM) SW option.

DTMB mode

☐ For digital terrestrial modulation according to the DTMB (Digital Terrestrial Multimedia Broadcast) standard. The DTMB mode requires the GNDMOD SW option, and enables one DTMB mux output.

[EDIT](#)

Mode selection implications

The selected operation mode will have an impact on the possible selection of output.

- **Analog mode:** for 1 or 2 analog RF and/or SDI output.
- **DVB-T mode:** for 1 or 2 digital terrestrial modulation (COFDM).
- **DVB-C mode:** for digital cable TV modulation (QAM), 1 to 4 DVB-C multiplexes.
- **J.83 Annex B mode:** for digital cable TV modulation (J.83 Annex B), 1 or 2 J.83 Annex B multiplexes.
- **J.83 Annex C mode:** for digital cable TV modulation (J.83 Annex C), 1 to 4 J.83 Annex C multiplexes.
- **Streaming mode:** for IP-TV output (TS over IP). Up to 20 IPTS out.
- **FM mode:** for up to 8 analog FM outputs.
- **DTMB mode:** for 1 DTMB out

For all the different operation modes, your CHAMELEON module must also be equipped with the appropriate SW options, see more details in §15.

ASI and IP for all operation modes

In all operation modes, input and/or output via ASI is available simultaneously. The ASI in/out can be used simultaneously with the modulated and IPTS outputs. The different operation modes also have capability for simultaneous IPTS (SPTS and/or MPTS) inputs and outputs. The number of IPTS in different operation modes are given to the right.

Number of IPTS¹⁾ in/out in different operation modes

- Analog: 2 IPTS in / 4 IPTS out
- DVB-T: 20 IPTS in / 4 IPTS out
- DVB-C: 20 IPTS in / 6 IPTS out
- J.83B: 20 IPTS in / 4 IPTS out
- J.83C: 20 IPTS in / 6 IPTS out
- Streaming: 4 IPTS in / 20 IPTS out
- FM: 8 IPTS in / 2 IPTS out
- DTMB: 10 IPTS in / 2 IPTS out

¹⁾ IPTS = SPTS and/or MPTS

9 Add and configure inputs


Go to Inputs

Click on the **Inputs** tab. Depending on the SW options in your CHAMELEON, you can configure inputs from:

- Tuner (up to 2 tuner inputs, note that available inputs depends on HW version)
- ASI (up to 2 ASI inputs)
- IP (up to 20 IPTS inputs, depending on Operation Mode)

Add an input

1. Click on **ADD NEW INPUT** to expand the input creation menu.
2. Select input type in the Choose input type drop-down list (ASI, DVB-C, DVB-S, DVB-S2, DVB-T, DVB-T2, IPTV. Selectable tuner inputs will depend on the tuner installed).
3. Enter the settings, and confirm/save by clicking the “green tick” ✓



Configure the input

For each type of input, you will get configuration settings in the expanded view.


1. Type a name for the input. This name will be shown in the overview of the inputs.
2. Fill out the required information/parameters and click **Save**.

Input status

If your settings were OK, the status will show you basic information and no error indication.

NAME ▾	TYPE	FREQ. (MHz)	STATUS
Hotbird 12437 H	DVB-S (RF 1)	12437	BER: <1.0E-08 Level: 75 dBμV


If your settings were not OK, a red exclamation mark  will indicate an error, and the mouse-over will give indication about the art of the error.

NAME ▾	TYPE	FREQ. (MHz)	STATUS
Hotbird 12437 H	DVB-S (RF 1)	12437	BER: N/A Level: 75 dBμV 

Tuner is unlocked!


9.1 Add ASI and IP inputs

Adding ASI inputs

Go to **Inputs**, and click on **ADD NEW INPUT**. Select **ASI** in the drop down list for Input type. Type a name for your ASI input. Select the Physical port from the drop down list. Port 1 is the top BNC 1 connector, port 2 is the lower BNC 2 connector. Click the “green tick”  to save the settings.



ASI inputs automatically detects the incoming bit rate.



Add IP inputs

Go to **Inputs**, click **ADD NEW INPUT**. Select **IPTV** in the drop down list for Input type list. Type a name for your new IPTV input. Select Bitrate mode:

- CBR Automatic (auto-detects the incoming constant bit rate)
- CBR Manual (manual setting of constant bit rate in)
- VBR (Variable bit rate in)



Select Network interface. If no network interface is available, you can use the link **Manage interfaces**. More information about Network Interfaces are given in §13.1

Select Routing scheme, Multicast or Unicast:

- For Multicast; enter the Multicast address and Port
- For Unicast: enter the Port (address will be the same as the IP address of the streaming interface)

Click the “green tick”  to save the settings.


Input status and edit settings

If your settings were OK, the status will not indicate any error. Expand the input by clicking the  in front of the input name to see further information. Click the  in front of Settings to edit settings.

NAME ▾	TYPE	FREQ. (MHz)	ADDRESS	BITRATE	STATUS
» Hotbird 12437 H	DVB-S (RF 1)	12437			BER: <1.0E-08 Level: 76 dBµV
» My IPTV in	IPTV		239.123.51.1:1234	3.69 Mbit/s	Protocol: UDP
Status: No error					
Services: 1, TSID: 17003, ONID: 0					
Active configuration: Primary					
Detected protocol: UDP					
▾	SETTING	VALUE			
	Name	My IPTV in			
	Protocol	UDP			
	Bitrate mode	VBR			
	Network interface	IP streaming interface			
	Routing scheme	Multicast			
	Multicast address	239.123.51.1			
	Port	1234			
	Source address	0.0.0.0			
	Active configuration	Primary			
	Redundancy mode	Off			
» Alternative configurations					

9.2 Add tuner inputs

Adding tuner inputs

1. Go to **Inputs** and click on **ADD NEW INPUT**.
2. Select the tuner type in the Input type list.
3. Type a name for your input.
4. Select the Physical port from the drop down list. Port 1 is the top F-connector (RF in 1), port 2 is the lower F-connector (RF in 2), see picture in §9.1.
5. Fill out the required settings and click the “green tick”  to save the settings.

! The available tuner input types will depend on the SW options, and on your HW.

Note that each input type has its own set of input settings. Below some examples.

Example of terrestrial input settings

ADD NEW INPUT

Input Type	DVB-T
Name	My DVB-T input
Physical port	RF 2
Frequency (MHz)	E44
Bandwidth	658
	8 MHz

Example of satellite input settings

ADD NEW INPUT



Input Type	DVB-S
Name	Mu DVB-S input
Physical port	RF 2
Transponder frequency (MHz)	10744
LNB type	Universal
Polarisation	Horizontal
22 kHz tone	Auto
Symbol rate (kbaud)	22000
FEC	Auto
Voltage	Auto
DiSEqC type	4-way
Source	1

Example of cable TV input settings

ADD NEW INPUT

Input Type	DVB-C
Name	My DVB-C input
Physical port	RF 2
Frequency (MHz)	E35
	586
Symbol rate (kbaud)	6875
Constellation	Auto

Input status and edit settings

If your settings were OK, the status will not indicate any error. Expand the input by clicking the  in front of the input name to see further information. Click the  in front of Settings to edit settings.

NAME	TYPE	FREQ. (MHz)	STATUS
Hotbird 12437 H	DVB-S (RF 1)	12437	BER: <1.0E-08 Level: 76 dBµV
Status: No error Services: 47, TSID: 1, ONID: 1 SNR: 12.1 dB, BER: <1.0E-08, Level: -33 dBm 76 dBµV			
SETTING			
VALUE			
Name	Hotbird 12437 H		
Physical port	RF 1		
Transponder frequency (MHz)	12437		
LNB type	Universal		
Polarisation	Horizontal		
22 kHz tone	Auto		
Symbol rate (kbaud)	27500		
FEC	Auto		
Voltage	Auto		
DiSEqC type	4-way		
Source	2		

10 Add and configure outputs

Go to OUTPUTS

Depending on SW options, and Operation mode, you can configure up to:

- 2 Analogue RF out (PAL, SECAM)
- 8 analogue FM radio
- 2 SDI out
- 2 ASI out
- 2 DVB-T out
- 4 DVB-C out
- 2 J.83 Annex B out
- 4 J.83 Annex C out
- 1 DTMB out
- 20 IPTS out



ASI in/out and SDI shares the 2 BNC ports. These ports are controlled by software settings.

Add and configure an output

ADD NEW OUTPUT	
Output Type	ASI Change operation mode
Output enabled	ON <input checked="" type="checkbox"/> OFF
Name	My ASI output
Physical port	BNC 1
Bitrate (Mbit/s)	40
<input checked="" type="checkbox"/> <input type="checkbox"/>	

In the **Outputs** tab, click **ADD NEW OUTPUT**.

1. Select output type (ASI, SDI, IPTV, DVB-C, J.83 Annex B, J.83 Annex C, DVB-T, ANALOG, FM, DTMB) from the drop-down list. The available selection depends on Operation mode and SW options.


For each type, you will get different configuration settings in the expanded view.

2. Fill out the required information/parameters

3. Click the “green tick”  to save the settings.

Output status

After saving, the status of the configured outputs is shown. If e.g. too many outputs are configured, or an output that is not supported in the current Operation mode, there will be an error message displayed.



10.1 Add and configure analogue (PAL, SECAM) outputs

Adding analogue output

Select Analog mode as Operation Mode, see also §8.

1. In the **Output**, select **Analog** in the Output type list
2. Type a name for the output

Decoder settings

1. Select decoder instance (there are 2 decoder instances available)
2. Select the service in the Services drop down list. Note: if the incoming service is encrypted, you have to select the input to the CAM in **Settings / Common Interface**, and select to descramble the service in the Service Management. In the Services drop down list, make sure to select the decrypted service.
3. Select PAL or SECAM video standard in the Video standard drop down list
4. Select audio language (Optional. If only 1 audio language is transmitted use "Default")

Subtitling settings

1. Select Subtitling ON
2. Select subtitling language from the drop down list, or enter the 3 letter language code according to ISO 639-2.
3. Select Subtitle priority, Subtitle type, Teletext codepage, and optionally Subtitle conversion and WSS subtitle configuration

Modulator settings

1. Select TV standard, Audio system and Frequency table from the drop-down lists
2. Enter an output frequency, or select a channel from the drop down list.
3. Enter an output carrier level

Save settings

Click the “green tick”  to save the settings.

Advanced settings


To get access to the advanced settings, click the  in front of the Advanced settings.

ADVANCED SETTINGS	
DECODER SETTINGS	MODULATOR SETTINGS
OSD Test pattern <input checked="" type="radio"/> ON <input type="radio"/> OFF	Video bandwidth (MHz) <input type="text" value="5.0"/>
Video conversion <input type="text" value="Ignore"/>	Picture carrier modulation depth <input type="text" value="90%"/>
WSS configuration <input type="text" value="Auto"/>	Video group delay pre-correction <input type="text" value="B/G general"/>
Stereo mode <input type="text" value="Stereo"/>	Test lines <input checked="" type="radio"/> ON <input type="radio"/> OFF
VPS signaling <input type="text" value="Off"/>	Audio deviation <input type="text" value="0 dB"/>
	Mono subcarrier level <input type="text" value="Auto"/>
	Stereo subcarrier level <input type="text" value="Auto"/>

Language selection for audio language and subtitles

For audio language, you can use default language, select the language from the drop down list, or manually enter the 3 letter language code according to ISO 639-2. When you use the manual settings, you can find the PID number in the Service Management, on the input side, when expanding to service level.

For subtitle language, you can select language from the drop down list, or enter the ISO 639-2 code.

 **Dolby audio decoding requires hardware revision 1402 or higher, and the GNDOL SW option.**

Important information about HD to SD downscaling

The MPEG decoder can downscale one service from MPEG2/4 HD to SD. When using the MPEG decoder for downscaling, you are limited to 1 analogue output.


Dual mono output


It is possible to set up one analogue output with dual mono sound (different languages in left/right audio channel).

1. Create 2 analogue outputs
2. Set up both decoders with the same service but different audio languages
3. Select Stereo mode: Dual mono (Decoder settings)
4. Deactivate the second analogue output (Output enabled = OFF)
5. In the Modulator settings, select Audio system A2 Dual mono or NICAM Dual mono
6. Select Dual mono source: Both decoders

10.2 Add and configure ASI, SDI and FM outputs



Add ASI outputs

1. In the **Output**, select **ASI** in the drop down list for Output Type
2. Enter name, physical port and bitrate
3. Click the “green tick”  to save the settings.




ADD NEW OUTPUT ^


Output Type	ASI
Output enabled	ON <input type="radio"/> OFF <input type="radio"/>
Name	My second ASI out
Physical port	BNC 2
Bitrate (Mbit/s)	45

Add and configure SDI outputs

Select Analog Operation Mode



1. In the **Output**, select **SDI** in the Output Type list
2. Select the service in the Services drop down list
3. Set the audio language and subtitle settings
4. Optionally, select Audio language
5. Click the “green tick”  to save the settings.



ADD NEW OUTPUT ^

Output Type	SDI
Output enabled	ON <input type="radio"/> OFF <input type="radio"/>
Name	My SDI output
Decoder instance	Two
Service	CCTV-4
Audio language	Default
Subtitling	ON <input type="radio"/> OFF <input type="radio"/>

► Advanced settings
► TV OSD
► Radio OSD


 




See also §10.1 for more information about these settings.

Add FM radio outputs

Select FM mode as Operation Mode



1. In the **Output**, select **FM** in the drop down list for Output Type
2. Select the service in the Services drop down list
3. Enter Channel frequency and Carrier level
4. Optional: for RDS signalling, select the PI, PS and PTY sources, and enter the values if using manual settings.
5. Click the “green tick”  to save the settings.



ADD NEW OUTPUT ^

Output Type	FM	Change operation mode
Output enabled	ON <input type="radio"/> OFF <input type="radio"/>	
Name	My FM out	



DECODER SETTINGS		MODULATOR SETTINGS	
Decoder instance	One	Audio deviation	0 dB
Service	ESP2 NE Norwegian	Channel frequency (MHz)	103.2
RDS	ON <input type="radio"/> OFF <input type="radio"/>	Carrier level (dBµV)	70
PI source	From UECP		
PS source	From UECP		
PTY source	From UECP		


 

10.3 Add and configure DVB-T, DVB-C, J.83 ANNEX B, J.83 ANNEX C and DTMB outputs

Add DVB-T outputs

Select Operation mode DVB-T under **Settings**

1. In the **Output**, select **DVB-T** in the Output Type list
2. Enter a name for the output
3. Select Frequency table (CCIR or OIRT)
4. Select output channel, or set the output frequency in MHz
5. Select output bandwidth (5, 6, 7 or 8 MHz)
6. Set the output carrier level
Click the “green tick”  to save the settings.
7. Select the Forward error correction (FEC), the Guard interval (GI), the Carrier mode and the Constellation from the dropdown lists
8. Click the “green tick”  to save the settings.



The screenshot shows the 'ADD NEW OUTPUT' dialog with the following settings:

Parameter	Value
Output Type	DVB-T
Output enabled	ON
Name	My DVB-T out
Frequency table	CCIR
Frequency (MHz)	E22
Bandwidth (MHz)	482
Carrier level (dBμV)	8
Forward error correction	7/8
Guard interval	1/32
Carrier mode	8k
Constellation	64QAM



Channel bonding. All output muxes within 40 MHz band (5 channels @ 8 MHz)


Add additional DVB-T outputs


Repeat the steps above.

The **Output Enabled ON/OFF** gives you the possibility to configure an output without adding it to your network. With Output enabled set to **OFF**, no signals will be transmitted.

Add DTMB output

Select Operation mode DTMB under **Settings**

1. In the **Output**, select **DTMB** in the Output Type list
2. Enter a name for the output
3. Select Frequency table (CCIR or OIRT)
4. Select output channel, or set the output frequency in MHz
5. Set the output carrier level
6. Select the Header length in the drop down list
7. Select the Interleaving length in the drop down list
8. Select the Constellation in the drop down list
9. Click the “green tick”  to save the settings.





The screenshot shows the 'ADD NEW OUTPUT' dialog with the following settings:

Parameter	Value
Output Type	DTMB
Output enabled	ON
Name	My DTMB output
Frequency table	CCIR
Frequency (MHz)	E27
Carrier level (dBμV)	522
Header length	74
Interleaving length	420 symbols
Code rate	M = 240
Constellation	64QAM

Add DVB-C outputs

Select Operation mode DVB-C under **Settings**


1. In the **Output**, select **DVB-C** in the drop down list for Output Type
2. Enter a name for the output
3. Select Frequency table (CCIR or OIRT)
4. Select output channel, or set the output frequency in MHz
5. Select Constellation in the drop-down list
6. Select QAM spectrum (Normal or Inverted)
7. Set the symbol rate
8. Set the output carrier level
9. Click the “green tick”  to save the settings.





Channel bonding. All output muxes within 40 MHz band (5 channels @ 8 MHz)

Add J.83 Annex B outputs

Select Operation mode J.83 Annex B under **Settings**


1. In the **Output**, select **J.83 Annex B** in the Output Type list
2. Enter a name for the output
3. Select Frequency table (CCIR or OIRT)
4. Select the output channel, or set the output frequency in MHz
5. Select Constellation in the drop-down list
6. Select interleaving mode in the drop-down list
7. Select QAM spectrum (Normal or Inverted)
8. Set the output carrier level
9. Click the “green tick”  to save the settings.





Channel bonding. All output muxes within 40 MHz band (5 channels @ 8 MHz)

Add J.83 Annex C outputs

Select Operation mode J.83 Annex C under **Settings**

1. In the **Output**, select **J.83 Annex C** in the Output Type list
2. Enter a name for the output
3. Select Frequency table (CCIR or OIRT)
4. Select the output channel, or set the output frequency in MHz
5. Select Constellation in the drop-down list
6. Select QAM spectrum (Normal or Inverted)
7. Set the symbol rate
8. Set the output carrier level
9. Click the “green tick”  to save the settings.





Channel bonding. All output muxes within 40 MHz band (5 channels @ 8 MHz)

Add additional DVB-C, J.83 Annex B or J.83 Annex C outputs


Repeat the steps above.

10.4 Add and configure IP (SPTS/MPTS) outputs

Configure a network interface for streaming (see also 12.1)

1. Go to **Networking** in the **Settings** tab, and select **Add interface**.
 - For GN01 or GN40 mounting, add a new network interface for the streaming port.
 - For GN50 mounting, add a new network interface to the backplane port.
2. Enter name for the interface, and IP parameters
3. Select **Streaming ON**, and click the “green tick”  to save the settings

Add IPTV outputs

1. In the **Output**, select **IPTV** in the drop down list for Choose output type
2. Select protocol, UDP or RTP
3. Select the bit rate mode, CBR or VBR
4. Set the output bit rate
5. Set the TTL (Time to live). The default TTL=255 => no limit for the lifespan of data.
6. Select Network interface
7. Set the destination (streaming) address and port.
8. Click the “green tick”  to save the settings

ADD NEW OUTPUT ^	
Output Type	<input type="text" value="IPTV"/> Change operation mode
Output enabled	ON <input checked="" type="checkbox"/> OFF <input type="checkbox"/>
Name	<input type="text" value="IPTV output example"/>
Protocol	<input type="text" value="UDP"/>
Bitrate mode	<input type="text" value="CBR"/>
Bitrate (Mbit/s)	<input type="text" value="35"/>
Time to live (hops)	<input type="text" value="255"/>
Network interface	<input type="text" value="IP streaming interface"/> Manage interfaces
Destination address	<input type="text" value="239.11.12.13"/>
Port	<input type="text" value="1234"/>


Multicast vs. Unicast

Multicast or Unicast transmission is selected automatically by the address range used. In IPv4, addresses **224.0.0.0** through **239.255.255.255** are designated as multicast addresses.

11 SERVICE MANAGEMENT, service & PID management

Service Management functionality and pre-requisites

The **Service Management** tab is the main view for handling remultiplexing, service selection, decryption, encryption and PID management. Before using the Service Management for management of services and PIDs, the inputs and outputs of the CHAMELEON module must be configured, see §9 and §10.



Service Management - left part for Inputs, right part for Outputs

The Service Management menu has 2 main parts. In the left part, information about inputs (Inputs, Services) are shown. The right part contains information about the outputs (Outputs, Services). You can select to show information about Inputs/Outputs or Services by clicking the tabs at the top of the 2 main views.

! Note that the Input and Output parts of Service Management can be collapsed/expanded by clicking on the expand/collapse icon at the top right:

- In the **Inputs view**, the listing is based on the configured inputs in the CHAMELEON, see §11.1
- In the **Outputs view**, the listing is based on the configured outputs in the CHAMELEON, see §11.1
- The **Services** views list all incoming/outgoing services, see §11.2

Information about inputs/outputs, services and PIDs can be accessed in any view, and the view you select to work with will depend on what you want to check or configure.

Service Management navigation

To navigate (expand/collapse) menu entries, the arrows in front of a menu is used:

- Click the ► icon to expand a menu and show the sub-menus
- Click the ▼ icon to collapse a menu and hide the sub-menus

Menu list sorting

All listings can be sorted according to any column name. Click a column name to sort the list entries by this column ▼ . Click again to sort in reversed order ▲ .

11.1 Navigating the In/Outputs view in Service Management

In the **Inputs** and **Outputs** views in **Service Management**, all inputs and outputs for the CHAMELEON are listed. The top entries in the navigation trees are the physical inputs and outputs configured. To navigate in the menus, use the ► and ▼ arrows to expand/collapse. The complete navigation graphs for these views are given in the next 2 pages.

The screenshot shows the CHAMELEON Service Management interface with two main panels: **Inputs** and **Outputs**.

Inputs Panel:

- Buttons: STATUS, INPUTS, OUTPUTS, SERVICE MANAGEMENT, SETTINGS.
- Tab: Inputs Services
- Table: INPUT, TYPE, SOURCE
- Row 1: Hotbird 12437 H, Tuner
- Row 2: IP input from 51, IP, 239.123.51.1:1234
- Row 3: PSI (From module: Chameleon 1 (Chameleon))
- Row 4: EMM
- Row 5: SERVICE, SID, TYPE, STATUS
- Row 6: ATM Rozrywka TV, 10511, [Icon], [Lock]
- Row 7: PMT: 32, PCR: 441
- Row 8: Type: Digital television service (MPEG-2 SD)
- Row 9: Running status: Running
- Row 10: STREAM, PID, BITRATE, LANG
- Row 11: [Icon], 442, 186.24 kbit/s, [Lock]
- Row 12: [Icon], 443, 195.24 kbit/s, [Lock]
- Row 13: [Icon], 441, 2.55 Mbit/s, [Lock]
- Row 14: [Icon], 444, 144.93 kbit/s, pol

Outputs Panel:

- Buttons: STATUS, INPUTS, OUTPUTS, SERVICE MANAGEMENT, SETTINGS.
- Tab: Outputs Services
- Table: OUTPUT, TSID, ONID, NID, LCN
- Row 1: My ASI output, 321, 17, 54, Nordig
- Row 2: Utilized bitrate: 7.02 Mbit/s (limit 40.00 Mbit/s)
- Row 3: Settings
- Row 4: PSI/SI tables
- Row 5: SERVICE, PROVIDER, SID, LCN, HD LCN
- Row 6: ATM Rozrywka TV, Cyfrowy Pols..., 10511, Not set, Not set
- Row 7: CASPIO-NET, Tadiran Scop..., 7220, Not set, Not set
- Row 8: Settings
- Row 9: STREAM, IN PID, OUT PID, STATE
- Row 10: [Icon], 161, 161, [Icon]
- Row 11: [Icon], 160, 160, [Icon]

Note that each entry in the lists has additional information via “mouse over” or hover that is displayed when you place the mouse pointer over an entry. The hover pop-up gives you information about the input or output name, and which module that the input or output is configured in.

From module: Chameleon 1 (Chameleon)

To add a service to an output, navigate to the Service level, click the ► and select the output to add the service to. More information about the managing services and PIDs in the System Management is given in §11.4 and §11.5.


The screenshot shows the CHAMELEON Service Management interface with the **Inputs** panel selected and the **Services** tab active.

Table: INPUT, TYPE, SOURCE


- Row 1: Hotbird 12437 H, Tuner
- Row 2: PSI/SI
- Row 3: SERVICE, SID, TYPE, STATUS
- Row 4: A3, 13940, [Icon], [Lock]
- Row 5: CANAL_ALGERIE, 13950, [Icon], [Lock]
- Row 6: CASPIO-NET, 7220, [Icon], [Lock]
- Row 7: CCTV-4, 7224, [Icon], [Lock]
- Row 8: CNC-001, 7257, [Icon], [Lock]
- Row 9: ESP2 Dutch, 13802, [Icon], [Lock]
- Row 10: ESP2 German, 13846, [Icon], [Lock]
- Row 11: ESP2 Greek, 13805, [Icon], [Lock]

Hover pop-up: Add ► My ASI output

Navigation graph for the Inputs view for Inputs in Service Management



Navigation graph for the Outputs view for Outputs in Service Management



11.2 Navigating in the Services view in Service Management

In the **Services** views in **Service Management**, all services in and out for the CHAMELEON are listed. The top entries in the navigation trees are the services from the configured inputs and outputs. To navigate in the menus, use the ► and ▼ arrows to expand/collapse. The complete navigation graphs for these views are given in the next page.

STATUS

INPUTS

OUTPUTS

SERVICE MANAGEMENT

SETTINGS


InputsServices

SERVICE	SID	TYPE	STATUS
A3	13940		
ATM Rozrywka TV	10511		
CANAL_ALGERIE	13950		
PMT: 3950, PCR: 3951			
Type: Digital television service (MPEG-2 SD)			
Running status: Running			
STREAM	PID	BITRATE	LANG
	3952	130.66 kbit/s	
	3951	3.38 Mbit/s	
CASPIO-NET	7220		
CCTV-4	7224		
CNC-001	7257		


OutputsServices

SERVICE	PROVIDER	SID	LCN	HD LCN
ATM Rozrywka TV	Cyfrowy Pols...	10511	Not set	Not set
CASPIO-NET	Tadiran Scopus	7220	Not set	Not set
SETTING	VALUE			
Name	CASPIO-NET			
Provider	Tadiran Scopus			
SID	7220			
LCN	Not set			
HD LCN	Not set			
PMT PID	7220			
STREAM	IN PID	OUT PID	STATE	
	161	161		
	160	160		


Navigation graph for the Services view for Inputs in Service Management



Navigation graph for the Services view for Outputs in Service Management




11.3 Managing services and PIDs in the Inputs part of Service Management

Management of services, PIDs etc. in the Service Management is handled via pop-up menus. The presence of a pop-up menu is indicated by a grey arrow, , at the end of an entry line. For the input services, the menus are used to select services to the outputs. For inputs from CI, descrambling of services or PIDs are also managed., see §11.6.


Entry line pop-up menus for Inputs in Service Management

The picture below shows the pop-up menus for the Inputs side of Service Management. Note that many of the entries contain important read-only information.

Detailed information about the different actions you can do in the pop-up menus are given in the following pages.



Managing services, PIDs and descrambling in Inputs in Service Management

Selection of services from inputs to outputs and descrambling of services or PIDs is managed via the pop-up menus indicated by a grey menu arrow, , tailing the different menu line entries. If no menu arrow is present, the information is read-only.

Input level pop-up menu

The pop-up menu at **Input** level allows you to add all services of an input to an output, or to connect an input transparently to an output. The **Character encoding** menu allows you select the encoding standard for the service names and for the provider names, see §11.4.2.




Add all services

Click on **Add all services to**, and select the output to add the services to.


This will result in the same as adding all services one by one on the Service level, and the automatic remultiplexing including creating correct PSI/SI will be done.

Connect transparently to

When you select **Connect transparently to**, all services of an input will be added to the selected output, and no change is done in the PSI/SI information. An output that is connected transparently to an input is marked with the  icon.

Service level pop-up menu


The pop-up menu at **Service** level allows you to add services one by one to an output by clicking **Add** and selecting the output in the new pop-up menu.



The **Descramble** command sets all PIDs to be descrambled. This command is only available for CI inputs. For more information about descrambling, see §11.6.

Stream level pop-up menu

The pop-up menu at **Stream** level allows you to descramble individual PIDs of a service. This menu is only available for CI inputs. The Descramble command on Stream level is activated only if the service is descrambled on Service level.



The Add to output and Add to service commands are covered in §11.3.1.



When selecting to descramble a PID, all other PIDs will become not selected for descrambling. Hence, if you need to descramble on PID level, make sure that you select descramble for all PIDs that you want to descramble.

11.3.1 Advanced management of tables and streams in Inputs

The Service Management in FW2.0 includes advanced management of tables (PSI/SI tables) and streams (ranging from EMM and ECM streams to elementary streams such as audio streams or video streams). This enables a wide range of advanced applications, where the user is assumed to have thorough knowledge of how to manage the tables and streams.


Please note that using this functionality also adds the possibility to create configurations that will not be according to standard application, and hence potentially can create problems in a network. It is advised to contact Support if there are any doubts about correct settings or applications.




Please contact Support if you are unsure about how to use the Advanced settings.

Pop-up menus for advanced applications

All menu entries below Service level at the Inputs part of Service Management have pop-up menus allowing you to add the entry to an output, or to a service of an output.



The presence of a pop-up menu is indicated by a grey arrow, , at the end of an entry line.

Advanced application example

This user manual will not cover all settings and applications for the advanced settings. As one example of possible usage of the advanced settings, you can add incoming unreferenced streams ("PIDs") to an output, or to a service in an output. This can be used e.g. for adding OTA data or EPG (EIT) from external sources.

For specific use cases, please contact Support for help or further documentation.

Inputs			
INPUT	TYPE	SOURCE	
Hotbird 12437 H	Tuner		
SVT	Tuner		
PSI/SI PID			
TYPE	PSI/SI PID	BITRATE	
CAT	1	15.11 kbit/s	
EIT	18	449.86 kbit/s	
NIT	16	600 bit/s	
PAT	0	15.11 kbit/s	
PMT	1810	15.01 kbit/s	
PMT	5840	15.01 kbit/s	
PMT	5800	15.01 kbit/s	
PMT	5640	15.01 kbit/s	
PMT	5540	15.01 kbit/s	
PMT	1290	15.11 kbit/s	
PMT	1280	15.01 kbit/s	
PMT	1240	15.01 kbit/s	
PMT	870	15.11 kbit/s	
SDT	17	4.79 kbit/s	
TDT	20	276 bit/s	
TOT	20	276 bit/s	
CA ID			
0x0500			
EMM PID			
EMM PID	BITRATE		
49	85.08 kbit/s		
55	14.91 kbit/s		
Other pids			
SERVICE	SID	TYPE	STATUS
Barnkanalen/SVT24	870		
Boxer Navigator	65534		
Kunskapskanalen	1240		
PMT: 1240, PCR: 1249			
Type: Digital television service (MPEG-2 SD)			
Running status: Running			
STREAM	PID	BITRATE	LANG
	1248	263.14 kbit/s	
	1249	6.15 Mbit/s	
	1004	263.14 kbit/s	dan, swe
SVT1 Tal Txt	1280		
SVT1 Tvärs	5800		
SVT1 Öst	5840		
SVT2 Tal Txt	1290		
SVT2 Tvärs	5540		
SVT2 Öst	5640		
IP input from 51	IP	239.123.51.1:1234	
CI 1	CI	IP input from 51	

11.4 Settings and management of Outputs in Service Management


For the Outputs part of Service Management there are pop-up menus and context menus where you type parameters. **Edit** in pop-up menus can open a context menu.

For the transport streams (TS) in the outgoing multiplexes, there are DVB Network related settings (TSID, ONID, Network ID, Network name, LCN type). There is also bitrate information for each output (utilized bitrate and configured (limit) bitrate).

For the services in the outputs, there are settings for service name, service provider name, SID (Service ID), LCN number and HD LCN number.

Entry line pop-up menus for Outputs in Service Management

The picture below shows the pop-up menus for the outputs side of Service Management. Note that many of the entries contain important read-only information. Detailed information about the different settings is given in the following pages.




Managing output settings, service settings and PIDs

Removing services, edit output TS settings (TSID, ONID, Network ID, Network name, LCN type), edit service settings (service name, service provider name, SID, LCN and HD LCN number), and edit stream settings (IN PID number, OUT PID number, block/unblock, set stream type) is managed via the menus in the Output side of Service Management.

Connecting outputs to EMMg and services to SCG is managed in the Outputs of Service Management. Elementary stream level scrambling is also managed in these menus. The scrambling related settings will be covered in §12.


Output level pop-up menu (remuxed)

The pop-up menu at Output level allows you to edit the main TS DVB Network settings, remove all services from an output, add an EMM connection (see §12), and set the Character encoding (see §11.4.2).



Output level pop-up menu (transparently connected)


The pop-up menu at Output level of an output that is transparently connected from an input allows you to disconnect the transparent connection or edit the Network ID (NID). Note that editing the NID is possible only if you have selected **Share NIT** to **ON** under **Setting**.



Note: there are 2 different ways to edit the DVB Network settings for an output:


- Select **Edit** in the **Output** level pop-up menu
- Navigate to the **Settings** under an output, and select **Edit** for this menu, see the following page

These 2 menus have different layout, but contain the same information, except that the Network name entry is not available from the Output level pop-up Edit.



Output / Setting level pop-up menu

The Edit in the pop-up at **Output / Setting** enters the menu for the DVB Network settings for TSID (Transport Stream ID), ONID (Original Network ID), Network ID, Network name and LCN type. See more information about the DVB Network settings in §11.9.




Output / PSI/SI tables level menu

Expanding the PSI/SI tables entry lists the tables, and for each table or sub-table there is a pop-up menu allowing you to Edit or Reset. These menus are generally intended for advanced settings, and will be covered in §11.4.1.


Output Service level pop-up menu

The pop-up at Service level allows you to edit the service settings (service name, service provider name, SID, LCN and HD LCN number). The **Revert changes** will reset all service settings to the original values. **Remove** will remove this service from the output. **Connect to / Disconnect from SCG** (for scrambling) is described in §12. The **Character encoding** menu allows you select the encoding standard for the service names and for the provider names, see §11.4.2.



Output Stream level pop-up menu

The pop-up at stream level allows you to edit the Out PID value, set the stream type, block (or unblock) the stream in the output and scramble the stream. Scrambling is described in §12.



11.4.1 Advanced management of tables and streams in Outputs

The Service Management in FW2.0 includes advanced management of tables (PSI/SI tables) and streams (ranging from EMM and ECM streams to elementary streams such as audio streams or video streams). This enables a wide range of advanced applications, where the user is assumed to have thorough knowledge of how to manage the tables and streams.

Please note that using this functionality also adds the possibility to create configurations that will not be according to standard application, and hence potentially can create problems in a network. It is advised to contact Support if there are any doubts about correct settings or applications.



Please contact Support if you are unsure about how to use the Advanced settings.

Advanced application example

This user manual will not cover all settings and applications for the advanced settings. As one example of possible usage of the advanced settings, you can create a service in an output without adding a service from the Input part of Service Management.

SERVICE	PROVIDER	SID	LCN	HD LCN
ADD NEW SERVICE				
Name	My new service			
Provider	ACME			
SID	1235			
LCN	Not set			
HD LCN	Not set			
PMT PID	1235			

Create service

For specific use cases, please contact Support for help or further documentation.

PSI/SI table management

All PSI/SI tables are listed under the PSI/SI table entry, and can be displayed by clicking the arrow ► in front of the entry line. The general pop-up menu is allows you to edit the table settings (enabled On / OFF, table repetition rate), or reset to the default values. For most tables, you can also create descriptors and/or block incoming descriptors.

As an example of PSI/SI table management, all the EIT Actual Schedule and EIT Other Schedule tables can be enabled or disabled, allowing you to modify the “EPG” data transmitted.

For specific use cases, please contact Support for help or further documentation.

Outputs					Services
OUTPUT	TSID	ONID	NID	LCN	
My ASI output	321	17	54	Nordig	
Utilized bitrate: 13.06 Mbit/s (limit 40.00 Mbit/s)					
Settings					
PSI/SI TABLE	TABLE ID	ENABLED	REP. RATE (ms)		
PAT	0x00	On	100		
CAT	0x01	On	200		
PMTs	0x02	On	100		
TSDT	0x03	On	10000		
EIT PF actual	0x4E	On	2000		
EIT PF other	0x4F	Off	10000		
NIT actual	0x40	On	3000		
SDT actual	0x42	On	2000		
SDT other	0x46	On	10000		Edit Reset
TDT	0x70	On	20000		
TOT	0x73	On	20000		
AITs	0x74	On	2000		
EIT ACTUAL SCH	TABLE ID	ENABLED	REP. RATE (ms)		
0-3 days	0x50	On	10000		
4-7 days	0x51	Off	10000		
8-11 days	0x52	Off	30000		
12-15 days	0x53	Off	30000		
16-19 days	0x54	Off	30000		
20-23 days	0x55	Off	30000		
24-27 days	0x56	Off	30000		
28-31 days	0x57	Off	30000		
32-35 days	0x58	Off	30000		
36-39 days	0x59	Off	30000		
40-43 days	0x5A	Off	30000		
44-47 days	0x5B	Off	30000		
48-51 days	0x5C	Off	30000		
52-55 days	0x5D	Off	30000		
56-59 days	0x5E	Off	30000		
60-63 days	0x5F	Off	30000		
EIT schedule others					
Services					
Second ASI out	1021	8945	No id		

11.4.2 Character encoding

DVB specifies a number of standard encodings of text strings, e.g. Service Names and Service Provider Names. These include ISO 8859-1 ISO 8859-15, GB-2312, BIG5, and UTF8. To indicate the encoding used, there is a flag in the SDT. If there is no flag, the name decoding should use ISO 6937.

Some transmissions omit the flag, but choose not to encode in ISO 6937. You may also want to use an encoding that is not defined by DVB.

Character encoding settings for inputs

On the input side of Service Management, there are settings for text encoding for the Service Name and the Service Provider Name. These settings can be used if there is no encoding flag in the incoming SDT.



This setting only has effect if the input service does NOT have a flag for character encoding.

Character encoding settings for outputs

At the output side of Service Management, there are encoding settings at output level as well as at service level. A service will inherit the encoding of the output unless you have set a specific encoding setting for the service.

For input services:

- Selecting a character encoding only has effect if the incoming SDT is without character encoding flag

For output services:

- For a not changed service name, and the output encoding set to Automatic (default), the service name is copied directly from the inputs
- For a not changed service, and the output encoding set to anything other than Automatic, the service name is decoded (according to the setting/flag for inputs), and encoded with the selected output encoding
- For a changed service/service provider name, and the output encoding set to Automatic, the CHAMELEON tries to encode the configured service name in an encoding that fits the text, e.g. "abcd" is encoded with ISO 6937 while "ääö" encoded with ISO 8859-9
- If the service/service provider name is changed and the output encoding is set to anything other than Automatic, the name will be encoded with the set encoding.

- Automatic
- Big5-HKSCS
- CP1251 (Windows-1251)
- GB-2312
- ISO-8859-1
- ISO-8859-2
- ISO-8859-3
- ISO-8859-4
- ISO-8859-5
- ISO-8859-6
- ISO-8859-7
- ISO-8859-8
- ISO-8859-9
- ISO-8859-10
- ISO-8859-11
- ISO-8859-13
- ISO-8859-14
- ISO-8859-15
- UTF-8 (Unicode)
- UTF-16 (Unicode)
-
- No DVB signaling

In all cases except the first, for "No DVB signalling" the encoding used is removed.

11.5 Descrambling and Common Interface

11.5.1 Common Interface and CAM/smart card

Descrambling requires a CAM to be inserted in one of the CI slots, and a smart card with the rights for descrambling the services. Note that multi-descrambling using professional CAMs is supported. CI settings are managed in the **COMMON INTERFACE** menu under **SETTINGS**.

Insert the CAM and smart card in the CI slot


Insert the CAM and smart card into the correct CI slot. From a rear view, CI slot 1 is to the left, CI slot 2 to the right.




Make sure that CAM is inserted with text side to the right

Select CI source – set which input to be connected to the CI slot

In the **COMMON INTERFACE** menu, Click **Edit**. Type a name for the CI. This name will appear in the Service Management as a input with type CI.



In the drop-down list of Select CI source, select the input to be connected to this common interface slot. The Bitrate selection in the drop-down list (72 Mbps, 62 Mbps, 55 Mbps) can normally be left at the default value 72 Mbps for all modern CAMs.



11.5.2 Descrambling – Service level & PID level

After selecting CI source in the **COMMON INTERFACE** menu, a new “input” of type CI will be displayed in the Inputs part of Service Management.

Select the services to be descrambled

Click the edit arrow of the service you want to descramble, and select **Descramble** in the popup menu. To output a descrambled service, add the service from CI input to an output (see §11.4).



Descrambling status indication icons



Scrambled (service or PID)



Unsuccessful descrambling (complete service or individual PID)



Descrambled (complete service or individual PID)



Unsuccessful partly descrambled service




Partly descrambled service (some of the services PIDs are descrambled)

PID level descrambling

At the PID level in the Inputs of Service Management, click the edit arrow of the PID you want to descramble, and select **Descramble** in the popup menu.


NOTE: When selecting to descramble a PID, all other PIDs will by default be selected not to be descrambled. Hence, if you descramble on PID level, make sure that you select to descramble all PIDS that you want to descramble.



Descrambling for analogue output

In Operation mode Analog you have to use the **SERVICE MANAGEMENT** for handling the decryption. The analogue output service selection is made in the output menu, and when a CI source has been set, the list of available services for analogue output will include the services routed via the CAM.

11.6 Remultiplexing and PSI/SI



Remultiplexing

In a CHAMELEON, remultiplexing is automatically done as services are selected from the inputs to the outputs. As such, all remultiplexing is managed in **SERVICE MANAGEMENT**.

PSI/SI Management

The PSI/SI of the outputs are automatically generated as services are assigned to the outputs. Selecting services from a single input, or selecting services from several inputs both result in the updating of the PSI/SI tables of the outputs.



Note that the SW option GNMUX is required for selecting services from several input sources to one output, and that the SW option GNSYMUX is required for sharing PSI/SI information between Chameleons.

DVB-Network PSI/SI Management

To create a DVB-network-wide correct PSI/SI structure, all CHAMELEONS in the same DVB network must be able to share PSI/SI information. The interconnection between the CHAMELEONS is enabled by the **HEADEND SYSTEM MANAGEMENT** functionality, see §11.10.

Further, the GNSYMUX SW option must be active to allow the interchange.

11.7 Service listings and service types

Input service listings

The services of an input transport stream (TS) or an output TS can be listed by navigating to the service level, see §11.1.

In the Inputs view of Service Management, expand an input, and expand Services to get a list of all services from this input.

To view a list of input services from all configured inputs, click on the Services tab to the right of the input side of Service Management.

Service listing information and types

The services in the input service listings have information columns SERVICE (service name), SID (service_id), TYPE (service type) and STATUS (indicating scrambling status).

The TYPE is indicated by icons (and also has mouse-over textual information):

Radio service



TV service



"Private data" (user defined)



Data broadcast service



INPUT		TYPE	SOURCE	
CI 1	CI	Thor		
PSI/SI				
EMM				
SERVICE	SID	TYPE	STATUS	
SVT1	4402			
PMT: 297, PCR: 8190				
Type: Digital television service (MPEG-2 SD)				
Running status: Running				
ECM				
TYPE	PID	BITRATE	LANG	
	688	262.17 kbit/s	swe	
	524	10.22 Mbit/s		
	576	299.62 kbit/s	swe	
SVT1	2702			
SVT1 Dalarna	3031			
SVT1 Gävleborg	3038			
SVT1 Jämtland	3039			
SVT1 Jönköping	3040			
SVT1 Mitt	3030			
SVT1 Nord	3028			
SVT1 Småland	3036			
SVT1 Syd	3037			
SVT1 Talande Text...	3026			
SVT1 Tvårs	3033			
SVT1 Varmland	3032			
SVT1 Väst	3034			
SVT1 Västerbotten	3029			
SVT1 Öst	3035			
SVT2	4403			
SVT2 Dalarna	3001			
SVT2 Gävleborg	3023			
SVT2 Jämtland	3024			
SVT2 Jönköping	3025			
SVT2 Mitt	3004			
SVT2 Nord	3002			
SVT2 Småland	3010			
SVT2 Syd	3011			
SVT2 Talande Text...	3027			

Output service listings

The services of an input transport stream (TS) or an output TS can be listed by navigating to the service level, see §11.1.

In the Outputs view of Service Management, expand an output, and expand Services to get a list of all services from this output.

To view a list of output services from all configured outputs, click on the Services tab to the right of the output side of Service Management.

Output service listing and information

The services in the output service listings have information columns SERVICE (service name), PROVIDER (service provider name), SID (service_id), LCN (logical channel number) and HD LCD.

Outputs Services				
OUTPUT	TSID	ONID	NID	LCN
T out Tango	17001	2334	2111	Nordig
Utilized bitrate: 14.71 Mbit/s (limit 31.67 Mbit/s)				
Settings				
SERVICE	PROVIDER	SID	LCN	HD LCN
Discovery Channel	SKY	14	1	51
NatGeo Wild	SKY	12	2	52
Sky Bundesliga 1	SKY	223	3	53
Sky Select	SKY	18	4	54







11.8 PIDs and PID listings

PIDs and PID listings and PID types

The PIDs of an input transport stream (TS) or an output TS can be listed by navigating to the PID level, see §11.1. In the Inputs view of Service Management, all PIDs including PSI/SI PIDs, EMM PIDs and unreferenced PIDs are listed.

The Outputs view lists the audio PIDs, video PIDs, teletext PIDs and data PIDs related to the services.

In the Services views of the Service Management, the service PIDs (audio PIDs, video PIDs, teletext PIDs and data/unknown PIDs) are listed.

Inputs Services			
INPUT		TYPE	
IP input examp...	IP	239.24.25.26 1234	
Satellite input...	Tuner		
PSI/SI PID	TYPE	BITRATE	
0	PAT	3.17 kbit/s	
1	CAT	3.17 kbit/s	
16	NIT	2.58 kbit/s	
17	SDT	13.59 kbit/s	
18	EIT	817.35 kbit/s	
20	TDT	3.00 kbit/s	
20	TOT	3.00 kbit/s	
100	PMT	6.72 kbit/s	
200	PMT	6.72 kbit/s	
300	PMT	6.66 kbit/s	
400	PMT	6.66 kbit/s	
500	PMT	6.66 kbit/s	
600	PMT	6.70 kbit/s	
SERVICE		SID	
arte		28724	
PMT: 400, PCR: 401			
PID	TYPE	BITRATE	LANG
401		6.88 Mbit/s	
402		203.60 kbit/s	deu
403		203.34 kbit/s	fra
404		262.62 kbit/s	deu
470		10.08 kbit/s	
2171		90.04 kbit/s	
Einsfestival 28722			
EinsPlus 28723			
PHOENIX 28725			
tagesschau24 28721			
Test-R 28726			

PID types and PID information

All PID listings have (at least) 3 columns:

- PID number
- PID type
- Bitrate

PSI/SI PID types are given as table acronyms such as PAT, CAT NIT. Service PID types are indicated with icons:









Audio PIDs: 

Teletext PIDs: 

Video PIDs: 

Data PIDs: 

For outputs, the incoming as well as the outgoing PID number is listed in the columns IN and OUT. Often the outgoing PID number is the same as the incoming PID number, but if the PID number already exists in the system, there is an automatic PID remapping to avoid PID clashes. Just as for the PIDs of the input services, the stream (PID) types are indicated with icons.

SERVICE	PROVIDER	SID	LCN	HD LCN
ATM Rozrywka TV	Cyfrowy Pols...	10511	Not set	Not set
Settings				
STREAM	IN PID	OUT PID	STATE	
	442	442		
	443	443		
	441	441		
	444	444		

11.9 Outputs TS DVB Network settings

TSID, ONID, NID, LCN type and Network Name

Each outgoing TS has a set of identifiers: TSID (transport stream ID), ONID (original network ID), NID (network ID), LCN (logical channel numbering type) and Network Name. All identifiers can be edited by clicking the edit arrow

OUTPUT	TSID	ONID	NID	LCN	
ASI out 52 (to...	17001	4	4	None	
November T out...	55	23	3131	Nordig	
Utilized bitrate: 5.30 Mbit/s (limit 31.67 Mbit/s)					
SETTING		VALUE			
TSID		55			
ONID		23			
Network ID		3131			
Network name		Sixten			
LCN		Nordig			

TSID

The transport_stream_id (TSID) is a 16-bit field which serves as a label for identification of this TS from any other multiplex within the delivery system. Hence, the TSID has to be unique within a DVB Network.

ONID and NID

The SI uses two labels related to the concept of a delivery system, namely the network_id (NID) and the original_network_id (ONID). The latter is intended to support the unique identification of a service, contained in a TS, even if that TS has been transferred to another delivery system than the delivery system where it originated.



If no network_id (NID) is set, the outputs will not contain any NIT.

Network Name

A string of characters that specify the name of the delivery system about which the NIT informs. A change of the Network Name is propagated to all TS with the same NID.

LCN (LCN type)

The LCN type specifies which LCN implementation to use. For a DVBNetwork, the LCN type should be the same for all outgoing muxes. Available LCN types are Nordig, EACEM and ITC (Independent Television).



The LCN number is edited in the settings for each service.

11.10 Outputs services settings

Service name, service provider name, service ID and LCN number

Each service in an outgoing TS has a set of identifiers: Service name, service provider name, service ID (SID) and LCN number. These identifiers are listed for all output services. All identifiers can be edited by clicking the edit arrow

				Outputs	Services
SERVICE ▾	PROVIDER	SID	LCN	HD LCN	⚙️
▼ Discovery Channel	SKY	14	1	51	▶
▼ SETTING	VALUE				▶
Name		Discovery Channel			
Provider		SKY			
SID		14			
LCN		1			
HD LCN		51			
▶ Pids					
▶ NatGeo Wild	SKY	12	2	52	▶
▶ Sky Bundesliga 1	SKY	223	3	53	▶
▶ Sky Select	SKY	18	4	54	▶

SID

The service ID is a 16-bit field which serves as a label to identify this service from any other service within a transport stream (TS). Hence, the service ID is a unique identifier of a service within a TS.

Service name and service provider name

The service name and the service provider name is textual information used by the receivers to display information about the services.

LCN (LCN number) and HD LCN number

The LCN number, which will be used by a receiver to make a channel list, is edited for each service in each outgoing mux. For correct functionality, the LCN number must be unique for each service within a DVB network. For managing automatic reconfiguration of channel lists depending on receiver capability, the HD LCN can be used.

11.11 The System management and DVB Network PSI/SI


For creation of a network-wide correct PSI/SI structure in a DVB Network, information about PSI/SI has to be shared between the CHAMELEON modules in the same network. The basis for such a sharing is that the CHAMELEONS are connected via a switch, and that a communication is set up between the CHAMELEONS. Additionally, all CHAMELEONS that are to share PSI/SI information must have the SW option GNSYMUX.

The screenshot displays a web-based configuration interface for CHAMELEON modules. At the top, there is a 'Group Name' field with the value 'My group' and a 'Communication method' dropdown menu set to 'Broadcast'. Below these fields, there are two columns: 'Group units' and 'Selectable units'. The 'Group units' column contains two entries with their serial numbers: '0431113040500020' and '049011120100016'. The 'Selectable units' column contains three entries with their serial numbers: '0350009011900072', '0530112080800002', and '0530112080900002'. At the bottom of the interface, there are three buttons: 'REMOVE', 'SAVE', and 'CANCEL'.

Headend System management

Under **SETTINGS**, in the **HEADEND SYSTEM MANAGEMENT** menu, you can select CHAMELEONS in the same local (layer 2) network to be members in the same group, a HE Group.

When clicking **EDIT**, all CHAMELEON in the local IP network will be listed by their serial number.

To add a CHAMELEON to a HE Group, click the green  in the list of Selectable units. Please note that the settings done in one CHAMELEON will automatically update the headend System Management settings also for all CHAMELEONS in the same group.

DVB network and PSI/SI sharing – network settings

When setting up a system where PSI/SI information is shared, you must also select network settings for all outgoing transport streams. The network_id (NID) must be identical for all outgoing transport streams, and all the transport streams must have different Transport Stream ID (TSID), see also §11.9.



11.12 Transmodulation and transparent outputs

Connect input to output transparently


An input can be sent transparently to an output by selecting “**Connect transparently to**”. When an input is “**connected**” to an output, as default there is no change of the content of the transport stream from input to output:

- All services, with all PIDs are sent from the input to the output
- The PSI/SI tables are sent from input to output without any change or modification

Settings for transparent outputs

As an alternative to the default setting (no change of content or signalling) there are settings available for sharing NIT, Network ID (NID), Network name and Delivery system descriptor. You can also select to remove null packets from the output.

To edit these settings, click the ► for Settings, and then click the tailing ► and select Edit.



12 Encryption – DVB-CSA scrambling and Simulcrypt


Conditional Access System (CAS) general information

A conditional access system generally consists of two main subsystems:

- A scrambling subsystem that a) scrambles the signal to prevent non-subscribers from receiving it and b) descrambles the signal at the subscribers' receivers.
- An access control subsystem that processes access control messages to determine whether descrambling is to be performed.

A CHAMELEON used in this context contains a Control Word Generator (CWG) generating Control Words (CW) for the scrambling (DVB-CSA). To enable de-scrambling at the receiver side, the CW is transmitted in encrypted format as ECMs. The ECMs are created by the CAS, based on the CW, and an Access Criteria (AC) supplied by the CAS.

The access control system is handled by EMMs. EMMs are received from the CAS, and included in the outgoing transport streams.



CAS vs. CHAMELEON interface structure

When setting up a CHAMELEON for scrambling, there are 2 main interconnections between the CHAMELEON and the CAS to be established:

- The connection for receiving EMMs from the CAS
- The connection for transmitting CW/AC to the CAS, and receiving the ECMs

Apart from this, there are some parameters/identifiers that has to be set internally in the CHAMELEON.

EMM communication req's


- CHAMELEON IP address for the IP interface used for Simulcrypt, and port for receiving the EMMs (EMM port) has to be given to the CAS.
- The Client ID has to be provided by the CAS, and entered in the CHAMELEON UI when setting up the connection.

The internal identifiers that has to be set in the CHAMELEON UI is the EMMg name. The EMM PID will be automatically assigned by the Chameleon, and can be changed in Service Management.

ECM communication req's

- The CAS IP address to be entered in the CHAMELEON UI.
- The SuperCAS ID, specified by the CAS, has to be entered in the CHAMELEON UI.
- The ECM port, the port that CHAMELEON should connect to for the ECMs, must be supplied.
- The Access Criteria has to be given by the CAS.

The internal identifiers that has to be set in the CHAMELEON UI is the ECMg name.



12.1 Encryption - scrambling overview

Encryption overview

Scrambling of services, or PIDs in services, requires a connection to a CA Server (CAS). CHAMELEON can connect to the CAS via the management IP interface or via the streaming interface. For setting up, or changing a network interface, for scrambling, set Simulcrypt to “On”. For details about network interfaces, please refer to §13.1.

Setting up encryption in CHAMELEON includes the following steps:

1. Create your outputs, and add the services you want to have in your outputs
2. (Set up your CAS for EMM and ECM generation)
3. Add EMM Generator connections to the CHAMELEON SimulCrypt interface
4. Add EMM connection to the output(s)
5. Add ECM Generator(s) to the CHAMELEON SimulCrypt interface
6. Create Scrambling Control Groups (SCG) and set up connections to the ECMg
7. Connect the service(s) to be scrambled to an Scrambling Control Group (SCG)

Notes

- In FW version 1.8.2, you can encrypt DVB-C, DVB-T, DTMB, J.83 Annex B, J.83 Annex B and ASI outputs.
- The maximum number of PIDs that can be encrypted is 64 PIDs per output
- The maximum number of encryption keys (SCG) is 64.

The screenshot displays the 'Simulcrypt' configuration window, which is organized into three main sections: EMM, ECM, and SCG. Each section contains a table of configurations and an 'ADD' button.

EMM Section:

EMM	CLIENT ID	INTERFACE	PORT	PRIVATE	BW	STATUS
My EMMg	08000000	Default manage...	1718		100	Client connected

ECM Section:

ECM	SUPER CAS ID	HOST ADDRESS	PORT	INTERFACE	STATUS
My ECMg	08000000	172.19.99.70	2117	Default man...	Opened

SCG Section:

SCG	CP DURATION	SCRAMBLING POLICY	SCRAMBLING POLICY FALLBACK	STATUS
My Group	1000	Always	Keep using last CW	Scrambling

Below the SCG table, there are two expandable detail sections:

DETAIL 1:

DETAIL	VALUE
Status	Scrambling
Remux connected	Connected
Scrambling status	Scrambling
Current crypto period	376

DETAIL 2:

ECM	ENABLED	ECM ID	ACCESS CRITERIA	PRIVATE DATA
My ECMg	On	1	HEX 00000000	

Below the second detail section, there is another expandable detail section:

DETAIL 3:

DETAIL	VALUE
ECMG connected	Yes
Stream state	Opened
CW state	ECM recieved
Error state	No error

12.2 Add EMM Generator connections

The CA Server set-up for EMM and ECM generation is not covered by this manual. Please contact your CAS supplier for information.

The IP address to be entered in the CAS is the IP address of the CHAMELEON network interface used for SimulCrypt communication.

Adding an EMM Generator connection

In the **SimulCrypt** menu under **SETTINGS**, click **ADD** under the EMM Generators box.

1. Enter a name for the EMMg
2. Enter the Client ID (info from CAS supplier, often same as the superCAS). The Client ID should be entered as a hex number, but without the 0x prefix. As an example, if the Client ID is given as 0x320011ac, you should enter 320011ac in the UI. The Client ID should always be 8 hex digits.
3. Select the Network interface you are using. Select a Simulcrypt enabled interface in the drop-down list, or remain with Auto. If Auto, the Chameleon will scan all Simulcrypt enabled interfaces and check if a connection can be established based on port and Client ID.
4. Enter the PORT (as the port stated by the CAS)
5. Optionally,, enter private data
6. Set the EMM bandwidth (check with your CAS provider)
7. Click the green OK tick ✓

The screenshot shows the 'Simulcrypt' settings window. At the top, there's a title bar 'Simulcrypt'. Below it, a table with columns: EMM, CLIENT ID, INTERFACE, PORT, PRIVATE, BW, STATUS. The table is currently empty, displaying 'No content available!'. Below the table, there are input fields for adding a new EMM generator: a yellow button 'My EMMg', a yellow text box '0B000000', a dropdown menu 'Auto' (with a list showing 'Auto', 'Default management', and 'Simulcrypt Alain'), a yellow text box '1718', an empty white text box, and a yellow text box '100'. To the right of these fields are green and red status icons. At the bottom right, there is a grey 'ADD' button.

Adding another EMM Generator connection

Repeat the steps above.

EMM Generator connection status during initialisation


After configuring the EMMg, the CHAMELEON will start listening for a connection to the CA server. If the connection is established correctly, the STATUS of the EMMg is "Client connected".

Simulcrypt						
EMM	CLIENT ID	INTERFACE	PORT	PRIVATE	BW	STATUS
My EMMg	0B000000	Default manage...	1718		100	Client connected
DETAIL	VALUE					
Name	My EMMg					
Error state	No error					

12.3 Add EMM connection to the output(s)


Connecting an EMM Generator to an output

In **SERVICE MANAGEMENT**, for an output, click the grey arrow to the right of an output. In the pop-up menu, select "Add EMM connection". Select the EMM generator you want to use for this output.



EMM information, and EMMg removal

An output connected to an EMMg will have an EMM entry under **Settings**. To remove an EMMg, click the and select **Remove**



12.4 Add ECM Generator connections

The CA Server set-up for EMM and ECM generation is not covered by this manual. Please contact your CAS supplier for information.

Adding an ECM Generator connection

In the SimulCrypt menu under **SETTINGS**, click **ADD** under the ECM Generators box.

1. Enter a name for the ECMg (internal name/identifier, default name ECMg 1 is OK)
2. Enter the Super CAS ID (info from CAS supplier). The Super CAS ID should be entered as a hex number, but without the 0x prefix. As an example, if the Super CAS ID is given as 0x320011ac, you should enter 320011ac in the UI.
3. Enter the HOST ADDRESS, the IP address for the CAS (information from your CAS supplier)
4. Enter the PORT (information from your CAS supplier)
5. For Interface, select a Simulcrypt enabled interface in the drop-down list, or use Auto. If you use Auto, the Chameleon will try to connect using one interface at the time, and connection will be based on CAS IP address and port.
6. Click the green OK tick .

Simulcrypt

EMM	CLIENT ID	INTERFACE	PORT	PRIVATE	BW	STATUS
My EMMg	0B000000	Default manage...	1718		100	Client connected

ADD

ECM	SUPER CAS ID	HOST ADDRESS	PORT	INTERFACE	STATUS
No content available!					
My ECMg	0B000000	172.19.99.70	2117	Auto	

ADD

SCG	CP DURATION	SCRAMBLING POLICY	SCRAMBLING POLICY FALLBACK	STATUS
No content available!				

ADD

When the communication between the CHAMELEON and the CAS is established: STATUS is **Open**

ECM	SUPER CAS ID	HOST ADDRESS	PORT	INTERFACE	STATUS
My ECMg	0B000000	172.19.99.70	2117	Default man...	Opened

DETAIL

NAME	VALUE
Name	My ECMg
Status	Opened
Channel ID	0

12.5 Add SCG (Scrambling Control Group)

In the SIMULCRYPT menu, under SCG, click ADD to add a Group.

1. Enter a name for the SCG

2. Set the Crypto Period duration (CP Duration). This must be set to a duration higher than the minimum allowed CP duration set in the CAS.

3. Select Scrambling Policy in the drop-down list:

Never (never scramble)

All ECMGs connected (scramble only if all ECMGs are connected)

Any ECMg connected (scramble as soon as there is, or as long as there remains, a connection to any ECMg)

Always (scramble always, i.e. the outgoing service will always be scrambled with the created CW, even if there is no possibility for the CAS to create an ECM. If all connections to the CAS for ECM are lost nobody will be able to descramble)

SCG	CP DURATION	SCRAMBLING POLICY	SCRAMBLING POLICY FALLBACK	STATUS
No content available!				
My Group	10000	All ECMGs connected	Keep using last CW	

ADD

SCRAMBLING POLICY dropdown options:

- Never
- All ECMGs connected
- Any ECMG connected
- Always

4. Select Scrambling fall-back policy in the drop-down list:

Revert to clear (if connection to CAS lost for ECM, go to not scrambling)

Keep last CW (if connection to CAS lost for ECM, keep scrambling, but keep using the last used Control Word (CW), and the last received ECM. This means that even if the connection is lost, the Chameleon will continue scrambling using the last CW that will correspond to the last received ECM from the CAS, and receivers can continue descrambling..

The screenshot shows a configuration window with tabs: SCG, CP DURATION, SCRAMBLING POLICY, SCRAMBLING POLICY FALLBACK, and STATUS. The 'SCRAMBLING POLICY FALLBACK' tab is active. It displays a dropdown menu with three options: 'Keep using last CW' (selected), 'Revert to clear', and 'Keep using last CW'. There is also an 'ADD' button on the right.

12.6 Edit Group in SCG (set up connection to ECMg)

Scrambling Control Group (SCG) (ETSI TS 103 197 V1.5.1): data structure gathering together in one same logical set the list of A/V streams scrambled at the same time with the same control word and the list of ECMs that are going to be generated with the identifier of their CA system and with their respective Access Criteria

After adding an SCG, edit the group to set up connection to an ECMg.

1. Set ENABLED to ON
2. Enter an ECM ID (You can select any numerical value, as long as it will be unique for your network.)
3. Select how to enter the ACCESS CRITERIA: HEX or ASCII
4. Enter the ACCESS CRITERIA (info from CAS supplier)
5. Optionally: enter private data
6. Click green OK tic

The screenshot shows the same configuration window as before, but now with the 'SCRAMBLING POLICY' tab active. It displays a table with columns: ECM, ENABLED, ECM ID, ACCESS CRITERIA, and PRIVATE DATA. The table has one row for 'ECMg 1' with the following values: ENABLED is 'ON' (indicated by a yellow button), ECM ID is '32', ACCESS CRITERIA is 'HEX', and PRIVATE DATA is '0b0a0b0a'. There is also an 'ADD' button on the right.

Status at this stage (before any service is connected to the Group in Service Management)

In the Group header: "No services connected"

Under Details:

- Status No services connected
- Scrambling status Scrambling
- Current crypto period 235 (increasing with new CW being created)

SCG	CP DURATION	SCRAMBLING POLICY	SCRAMBLING POLICY FALLBACK	STATUS
My group	10000	All ECMGs connected	Keep using last CW	No services connected
DETAIL		VALUE		
Status		No services connected		
Scrambling status		Scrambling		
Current crypto period		235		
ECM	ENABLED	ECM ID	ACCESS CRITERIA	PRIVATE DATA
ECMg 1	On	13	HEX 00000000	

12.7 Connect output services to an SCG (to a group)

Connecting a service to a Scrambling Control Group (SCG)

In **SERVICE MANAGEMENT** under **Outputs**, click the grey arrow to the right of a service.

In the pop-up menu, select **Connect to SCG**, and select the Scrambling Control Group you want to connect to.

When an output service connected to a Scrambling Control Group is expanded (clicking the leading ►), the SCG it is connected to is displayed below the service name.

Services that are scrambled are indicated with a padlock

For the services connected to an SCG, all video and audio PIDs will be scrambled.

Scrambling (or not) on PID level

In the PID listing of a scrambled service, you can select which PIDs you want to scramble or not. Click the grey arrow to the right of a PID, and select Scramble, and then Scramble or Do not scramble.

Outputs					Services
OUTPUT	TSID	ONID	NID	LCN	
ASI out scrambled	17001	32	33	Nordig	
Utilized bitrate: 2.84 Mbit/s (limit 40.00 Mbit/s)					
Settings					
EMM		PID			
Cryptoguard EMMg		6000			
SERVICE	PROVIDER	SID	LCN	HD LCN	
EU TV	ESS	7704	1	Not set	
Inedit TV	ESS	1059	2		
Edit Revert changes Remove Connect to SCG Disconnect Character encoding					
My group					

Outputs					Services
OUTPUT	TSID	ONID	NID	LCN	
ASI out scrambled	17001	32	33	Nordig	
Utilized bitrate: 3.39 Mbit/s (limit 40.00 Mbit/s)					
Settings					
EMM		PID			
Cryptoguard EMMg		6000			
SERVICE	PROVIDER	SID	LCN	HD LCN	
EU TV	ESS	7704	1	Not set	
Settings					
ECM		PID			
My group - ECMg 1		6001			
TYPE	IN	OUT	STATE		
7604	7604				
7504	7504				
Inedit TV					
ESS					
1059 2 Not set					

12.8 Simulcrypt menu for a correct set-up

The screenshot shows the 'Simulcrypt' configuration window with three main sections: EMM, ECM, and SCG.

EMM Section:

EMM	CLIENT ID	INTERFACE	PORT	PRIVATE	BW	STATUS
My EMMg	08000000	Default manage...	1718		100	Client connected

ADD

ECM Section:

ECM	SUPER CAS ID	HOST ADDRESS	PORT	INTERFACE	STATUS
My ECMg	08000000	172.19.99.70	2117	Default man...	Opened

ADD

SCG Section:

SCG	CP DURATION	SCRAMBLING POLICY	SCRAMBLING POLICY FALLBACK	STATUS
My Group	1000	Always	Keep using last CW	Scrambling

DETAIL

DETAIL	VALUE
Status	Scrambling
Remux connected	Connected
Scrambling status	Scrambling
Current crypto period	376

ECM Section:

ECM	ENABLED	ECM ID	ACCESS CRITERIA	PRIVATE DATA
My ECMg	On	1	HEX 00000000	

DETAIL

DETAIL	VALUE
ECMG connected	Yes
Stream state	Opened
CW state	ECM recieved
Error state	No error

ADD

Status information for OK set-up:

- **EMM Status:** Client connected
- **ECM Status:** Opened
- **SCG Status in Group header(s):** Scrambling (this will be the case if a service is connected to an SCG in Service Management)

Under Details in each group under SCG:

- **Status:** Scrambling
- **Scrambling status:** Scrambling
- **Current crypto period:** xyz (increasing with new CW being created)

Group Status (Connections under SCG):

- **Enabled:** ON
- **ECM ID:** existing and unique
- **Access criteria:** entered (as HEX or ASCII)

13 Settings: Managing the CHAMELEON module

Under **SETTINGS**, all module specific setting are managed.

NETWORKING: Networking settings for IP interfaces, see §13.1.

HEADEND SYSTEM MANAGEMENT: for CHAMELEON interconnection, see §11.11

MODE: selection of output mode, see §8

COMMON INTERFACE: In the COMMON INTERFACE menu, you select the input source for the CI, and you have access to the menu from the inserted CAM or CAMs. See §11.6.

SIMULCRYPT: for setting up EMM and ECM connections to a CA Server, and connecting ECM streams to Scrambling Control Groups, see §12 and sub-paragraphs.

DATE AND TIME: Settings for TDT source, and connection to NTP server. See §13.2

SCHEDULER: Task scheduling for scripts, see §13.3

SNMP: settings for SNMP, traps etc., see §13.4


SAP: settings for Session Announcement Protocol, see §13.5

USER MANAGEMENT: password protection for UI access, see §13.6

SOFTWARE AND ENTITLEMENT UPGRADE: Software upgrade, used both for uploading new FW and for uploading SW options (entitlement files), see §13.7

MAINTENANCE: For software reboot, factory reset and configuration backup and restore, see §13.8 and §13.9

LOG: For displaying logged data, see §13.10



13.1 Add and configure Network interfaces

Adding network interface for streaming

1. Click on **NETWORKING** in the **SETTINGS** tab
2. Click **Add new interface**
3. Type a name for the interface
4. Enter the IPv4 address, the Netmask and the Gateway
5. Select IGMP version
6. Select the capabilities needed for the interface (e.g. Streaming)
7. Click **SAVE**

! CHAMELEON has 2 IP ports in the front, a 10/100 Ethernet management port, and a GigE port for streaming. By default, there are no IP interfaces defined for the streaming port. When connecting a PC to the streaming port, the Ethernet port of the PC must have GigE capability. CHAMELEONS installed in a GN50 base unit use the backplane connector for both management and streaming interfaces.

Streaming

Status
MAC

CONNECTED
00:03:98:07:01:b4

+

Add new interface

Interface name

Streaming interface example

Use DHCP

ON OFF

IPv4

192.168.21.17

Netmask

255.255.255.0

Gateway

192.168.21.1

IGMP

IGMPv2

Use VLAN

ON OFF

System management

ON OFF

Web management

ON OFF

SNMP

ON OFF

Simulcrypt

ON OFF

Streaming

ON OFF

Command line interface

ON OFF

SAVE

CANCEL

+

Streaming interface

Creating a new streaming interface, see also §12.1

13.2 Date and time (NTP server access and Time sources)

The **DATE AND TIME** menu allows you to connect the CHAMELEON to an NTP server for establishing a valid UTC time reference. The time reference can be used as a time source for the creation of the TDT table. The TDT and TOT is used to enable receivers to detect correct time, and is also the time basis for the EPG (EIT).

The connection to an NTP server requires Internet connection to the CHAMELEON.

As an alternative, TDT information from incoming streams from the input sources can be used as a time source.

Date and time settings

UTC time

2013-06-12 13:08:05

Local time

2013-06-12 13:08:05 (UTC)

Time zone

(UTC+01:00) Sarajevo, SI

Adjust automatically for daylight saving time

ON OFF

NTP server(s)

ntp.pool.org

Separate addresses by adding a comma (",") after each address.

SAVE

CANCEL

NAME	TIME	USED	ENABLED
IP input example		NO	On
Satellite input e...	2013-06-12 13:17:11	YES	On

NTP server connection for UTC time reference

In the **DATE AND TIME** menu under **SETTINGS**, click **Edit**



1. Select your Time zone in the drop down list
2. Select daylight saving time **ON/OFF**
3. Enter a valid URL to an NTP server (e.g. ntp.pool.org)
4. Click **Save**

The added NTP server will be shown under Time sources. The UTC time from the NTP server is displayed, and if there are other valid time sources, their times will also be displayed.

As default, the NTP time reference is used for the TDT.

NAME ▾	TIME	USED	ENABLED	
IP input example		NO	On	⌵
NTP		YES	On	⌵
Satellite input e...	2013-06-12 13:17:56	YES	On	⌵

Selecting Time source for the TDT manually


1. Click the grey edit arrow  to the right of the Time source that is indicated as **YES** under USED
2. Select **OFF** in the drop-down list under ENABLED
3. Click the green confirmation symbol , or click enter

The Time reference will automatically switch to another Timer source.

13.3 Scheduler – commands scripting

The **Scheduler** is a task scheduler that can be used to run LUA commands from the UI of the CHAMELEON. The triggering of the tasks (set of commands) are based on local time (hour and minute), with the time source in **Date and Time** as reference.

Adding a new task

1. Click the green plus , or **Add new task**.
2. Enter a name for the task
3. Set the time the task should be run (hh:mm)
4. Enter the LUA commands in the Lua script window
5. Click **Save**



For information about available LUA commands, please contact Support.

Schedules

Adding a task will make the lua script provided to trigger once a day at the given time.

Local time 2013-06-10 11:57:18 (UTC)

➖ Add new task

Name New task example

Time 12:00

Lua script system.reset ()

SAVE CANCEL

Adding a new task

Running (testing) a task

You can test a task / the LUA commands manually by clicking **Execute Script**

13.4 SNMP

SNMP

Enable agent ON OFF

Agent port 161

Agent community read string public

Agent community write string private

Enable traps ON OFF

Traps address 192.168.21.17

Traps port 162

Traps community string public

Traps SNMP Version SNMPv2c

SAVE CANCEL

SNMP, Simple Network Management Protocol

SNMP can be used for alarms (traps/notifications) or to read (Get) or write (Set) information from/to a CHAMELEON.

To use SNMP, you need an NMS (Network Management System) that is connected to the CHAMELEON.

SNMP versions supported

In the current implementation, SNMP v1 and SNMP v2c is supported.

SNMP settings

- **Enable agent:** for turning the SNMP agent in CHAMELEON ON/OFF
- **Agent port:** UDP listen port (161 is the standard port used)
- **Agent community read string:** a “password” that has to be set in the NMS. The standard default string is “public”.
- **Agent community write string:** a “password” that has to be set in the NMS. The standard default string is “private”.
- **Enable traps:** for turning ON/OFF the alarm functionality
- **Traps address:** destination address of the NMS receiving the traps
- **Destination port:** destination port of the NMS receiving the traps
- **Traps Community string:** a “password”. Should be stated in the NMS. Default standard: “public”



Please contact Support for information about the MIB, MIB structure and NMS integration.

Supported traps and SNMP read/write in FW2.0

SNMP traps

- Tuner locked status change
- Loss of IP input bit rate (IP input bit rate = 0)
- IP input changed alternative input (for input redundancy)
- CHAMELEON temperature exceeding 65 °C
- Video decoder not running
- FM decoder running / not running
- PAT on input timed out
- Simulcrypt EMMg connected/disconnected
- Simulcrypt ECMg connected disconnected

SNMP read/write

- Tuner input status
- Tuner input configuration
- IP input status
- IP input configuration
- CHAMELEON module temp. (read only)
- CHAMELEON module name (read only)
- CHAMELEON module description (read only)
- GN50 slot number (read only)


13.5 SAP

Session Announcement Protocol (SAP) is a protocol for broadcasting multicast session information (corresponding to SDT and NIT for DVB transmissions). The information transferred over the SAP transport is formatted in compliance with the Description Protocol (SDP) format defined in RFC 2327. Under SAP, senders periodically broadcast SDP descriptions to a well-known multicast address and port. A SAP listening application can listen to the SAP multicasts and construct a guide of all advertised multicast sessions.

In Chameleon, when IP SPTS is used as output, the SAP can be enabled, and the Announcement interval can be set.


13.6 User management – password protection

The **User Management** allows settings of password for the UI. You can add users, and create passwords for each user.



The screenshot shows a 'User management' dialog box. At the top, it says 'Enabled/disable user authentication on this page.' Below this, there are two notes: 'Note: To be able to enable user authentication you must first create a user.' and 'Note: It is not possible to remove the last user without disabling user authentication first.' The 'User authentication' status is currently 'Off'. There is an 'EDIT' button. Below the status, there is a section titled 'Add new user' with a green plus icon. This section contains three input fields: 'User name' (containing 'User 1'), 'Password' (containing '*****'), and 'Password again' (containing '*****'). At the bottom right of this section are 'SAVE' and 'CANCEL' buttons.

Adding a user and password

1. Click **Add new user**, or the green plus 
2. Enter a user name
3. Enter a password
4. Confirm the password by entering it again
5. Click **Save**


Enabling password control

1. Select **User authentication ON**
2. Click **Save**



Make sure to remember your user names and passwords!

The web UI will respond with a "Authentication Required" where you should enter the user name and password.





The screenshot shows an 'Authentication Required' dialog box. It has a title bar with a question mark icon. The main text says: 'A user name and password are being requested by http://172.18.71.84. The site says: "Password protected web interface"'. Below this text are two input fields: 'User Name:' and 'Password:'. At the bottom are 'OK' and 'Cancel' buttons.

13.7 Software and SW options (entitlement) upgrade

Both FW and SW options are uploaded via the **Software and Entitlement Upgrade** in the **Settings** tab. Additionally, there is status information about the running software version, and, if a new software is uploaded, also about the latest (not running) software version.

Uploading Firmware

1. Click **Upload**. Click **Browse...** in the pop-up, and select the software file (*.bin file) to be uploaded from your computer
2. Click the **Upload** button
3. After upload complete message, reboot the module



Uploading software options

1. Click **Upload**. Click **Browse...** in the pop-up to browse for the software options file (*.ent) for this specific CHAMELEON module
2. Locate the software options file on your computer, and select it
3. Click the **Upload** button
4. Reboot the module



The SW options file will have the format <serial number>.ent. If you need to, you can download the entitlement file from the wisconnect.tv portal, see §4.

13.8 Module maintenance

Reboot

Some operations, such as upgrading the software, requires a reboot. Click the **Reboot** button to reboot the unit. During the rebooting process, Rebooting will be shown.

Reboot from Rescue mode


In very special circumstances the CHAMELEON can enter the Rescue mode. Click the **Reboot** button in the rescue mode to return to normal mode. Make sure to re-enter the IP address of your CHAMELEON in the address field of your browser to access the normal mode web GUI. In the rescue more, you can access basic functionality, and upload new software and software options.



13.9 Factory reset & Backup/Restore

Factory reset

The CHAMELEON module can be reset to the same status as when delivered from the factory, apart from the SW option that will remain as before factory reset, and the management IP address that will be kept. Go to the **Settings** tab, and **Maintenance**. Click on **Factory Reset**.




Backup and restore (saving configuration)

The backup and restore functionality gives you the possibility to save the complete configuration of a CHAMELEON to your computer. The stored file is in xml format.


The backup file can be used for e.g. copying configurations between different installations, or keeping a possibility to upload the original configuration to a CHAMELEON if you have tested a different configuration.

Additionally, the backup file is useful for sup



13.10 Log

The Log contains information about rebooting and failures/exceptions. You can also enable Syslog for logging more information. If the Chameleon has access to a time reference, the log entries are time stamped.



14 Status information

The **Status** tab gives a general overview over the CHAMELEON module. This page is also the starting page for the web UI.

MODULE IDENTIFICATION

Serial number and the HW version is shown. Further, there are 3 editable fields; Name, Location and Description. Clicking **Edit** below the box enables you to save your own selected information about this CHAMELEON module.

CONFIGURATION

The configuration box shows you the Operation mode, the Software version, and the enabled SW options. A warning will be shown if no operation mode is selected.

STATUS

Uptime (from last reboot), and current module temperature.

SERVICE LICENCE AGREEMENT

Shows if the CHAMELEON is registered at the wisiconnect.tv portal, and the expiry date of the service level agreement. If the demo/trial period is still on, the remaining demo uptime is displayed. If not, **Demo Expired** will be shown.

CHAMELEON control

STATUS INPUTS OUTPUTS SERVICE MANAGEMENT SETTINGS

MODULE IDENTIFICATION

Serial	0430011081500005
Hardware revision	1102
Name	Chameleon 1
Location	GN40
Description	S/S2/T/C

EDIT

CONFIGURATION

Operation mode	DVB-T mode
Software version	2.0
Software options	GNALL, GNHWUW

STATUS

Uptime	02m 09s
Temperature	47.5 °C

SERVICE LICENSE AGREEMENT (SLA)

Demo	Terminated
Registered	Yes
Expires	2014-10-09

15 Software options

CHAMELEON “products” range from receiver, to edge, to streamer and to scrambler. The different “products” realisations are controlled by the SW options enabled in any specific CHAMELEON module.

To get an overview of all different SW options currently available, please contact your sales representative or contact the CHAMELEON Support.

List of uploaded SW options

Under the **Status** tab, all enabled SW options are listed.

How to get and upload additional SW options

Please contact your sales representative at Taylor .Oldham



During DEMO trial period all SW options are enabled. Don't forget to order SW options needed for the actual installation.

Available software options

INPUT	PROCESSING	OUTPUT	MISCELLANEOUS
DVB-C Receivers GNC, GNDC	Common Interface Decryption GNCI, GNDCI	DVB-C Modulators GNCMOD, GNDCMOD, GNTCMOD, GNQCMOD	MPEG Encoder GNHWENC
DVB-S/S2 Receivers GNS2, GNDS2	Simulcrypt Scrambling GNSCR	J.83 Annex B/C Modulators GNJ83B, GNDJ83B, GNJDJ83C, GNQJ83C	System Management GNSYSMG
DVB-T/T2 Receivers GNT, GNDT, GNT2, GNDT2	Remultiplexing GNMUX, GNSYMUX	DVB-T Modulators GNTMOD, GNDTMOD	Service License Agreement GNM1, GNM3
ASI input & output GNASI, GNDASI	Redundancy GNRED	Analogue Modulators GNVMOD, GNDVMOD	All Software Options GNALL
IP Streaming input & output GNSTR, GNSTREC	Dolby AC3 GNDOL	FM Radio GNDFM, GNOCFM	
		DTMB Modulator GNDMOD	
		SDI output GNSSDI, GNDSDI	
		ASI input & output GNASI, GNDASI	
		IP Streaming input & output GNSTR, GNSTREC	